






CLASSIC MAZDA

As of November 2021

- 02 RX-7(FD) Rotary Engine Parts List
- 08 RX-7(FD) Restoration Parts List
- 13 RX-7(FC) Restoration Parts List




RX-7(FD) ROTARY ENGINE PARTS LIST

Part No.	Part Name	Image
N3G1 10 C50	Rr. Housing	
Fr: N3G1 10 B10 Rr: N3G1 10 B50	Rt. Housing	
N3A1 10 D00B	I.M.H	
N3F1 10 C00	Fr. Housing	


Part No.	Part Name	Image
Fr.:N3G1 10 E0Y Rr:N3G1 10 E1Y	Fr & Rr St.Gear	
N3G1 11 D00A	Ecc.Shaft	
N3YA 11 B10	Rotor	
N3F1 10 500	Fr. Cover	

Apex Seal & Spring

Side Seal & Spring




Oil Seal, O Ring & Spring






Corner Seal & Spring




Part No.	Part Name	Quantity	Image
N351 11 C00C	Apex Seal	6	
N326 11 C04A	Spring Apex Seal, Main	6	
N326 11 C06C	Spring Apex Seal, Sub	6	
N3Y1 11 C11	Side Seal	12	
NF01 11 C17	Spring Side seal	12	
N326 11 C20A	Corner Seal	12	
NF01 11 C24	Spring Corner Seal	12	
N3Z1 11 S10A	Set Oil Seal	1Set	
0820 11 341	O Ring inner	4	
0820 11 343	O Ring outer	4	
N225 11 351	Spring Inner Front	2	
1011 11 353A	Spring Outer Front	2	
N225 11 361	Spring Inner Rear	2	
1011 11 363A	Spring Outer Rear	2	





Short Engine
N3G1 02 200

RX-7(FD) RESTORATION PARTS LIST



No.	Part No.	Part Name	Category	Note	Image
1	N3A110450B	GAUGE,OIL LEVEL	ENGINE		
2	FB015681X	FASTENER,DUCT PANEL			
3	NF0113735	CLAMP,HOSE	AIR INTAKE		
4	N3A113971	HOSE,VENTILATION	FUEL SYSTEM	Image①	
5	N3A113972	HOSE,EVAPORATION	FUEL SYSTEM	Image②	
6	N3A220344A	TUBE,VACUUM	FUEL SYSTEM		
7	998330410	SCREW	AIR CLEANER		
8	N3Y113SL0	SENSOR,THROTTLE	THROTTLE BODY		
9	N3Y313SL0	SENSOR,THROTTLE	THROTTLE BODY		
10	J50120442	TUBE,VACUUM	EMISSON CONTROL		
11	N31820341A	HOSE,VACUUM	EMISSON CONTROL		
12	N3A420341	TUBE,VACUUM	EMISSON CONTROL		
13	N3A120341	TUBE,VACUUM	EMISSON CONTROL		
14	N3A320341A	TUBE,VACUUM	EMISSON CONTROL		
15	N3A420342	TUBE,VACUUM	EMISSON CONTROL		
16	N3A220342	TUBE,VACUUM	EMISSON CONTROL		
17	N3A120343A	TUBE,VACUUM	EMISSON CONTROL		
18	N3A420343	TUBE,VACUUM	EMISSON CONTROL		
19	N3A220343B	TUBE,VACUUM	EMISSON CONTROL		
20	N3A120344A	TUBE,VACUUM	EMISSON CONTROL		

No.	Part No.	Part Name	Category	Note	Image
21	N3A420344	TUBE,VACUUM	EMISSON CONTROL		
22	N3A420345	TUBE,VACUUM	EMISSON CONTROL		
23	N3A220345A	TUBE,VACUUM	EMISSON CONTROL		
24	N3A220346	TUBE,VACUUM	EMISSON CONTROL		
25	N3A220361A	TUBE,VACUUM	EMISSON CONTROL		
26	N3A120362	TUBE,VACUUM	EMISSON CONTROL		
27	N3A220362	TUBE,VACUUM	EMISSON CONTROL		
28	N3A220363	TUBE,VACUUM	EMISSON CONTROL		
29	N3A220371A	TUBE,VACUUM	EMISSON CONTROL		
30	N3A120372A	TUBE,VACUUM	EMISSON CONTROL		
31	N3A120661	GASKET,B.A.C. VALVE	EMISSON CONTROL		
32	N3F115611	GASKET	COOLING SYSTEM		
33	B61P15T56	WASHER,MOUNT.-FAN	COOLING SYSTEM		
34	9WNCB2700	CLAMP,HOSE	COOLING SYSTEM		
35	BPE818867A	CLIP			
36	FD0126233	SPRING 'V',REAR BRAKE	REAR BRAKE		
37	F1752661XA	BODY & PISTON(R),CAL	REAR BRAKE		
38	F1752671XA	BODY & PISTON(L),CAL	REAR BRAKE		
39	FD0133696	PIN,PAD-FRONT BRAKE	FRONT BRAKE		
40	FD0134461	BUSH,RUBBER-LWR ARM	FRONT SUSPENSION		

No.	Part No.	Part Name	Category	Note	Image
41	FD0142544	HOSE,FUEL-SEPARATOR	FUEL TANK	Image①	
42	FD0142545	HOSE,FUEL	FUEL TANK	Image②	
43	FD0142546	HOSE,FUEL-SEPARATOR	FUEL TANK	Image③	
44	HG3042561	HOSE NO.1,BREATHER	FUEL TANK		
45	FD3142511A	HOSE,BREATHER	FUEL TANK		
46	B45556149	SCREW,TAPPING-MUD GU	FUEL TANK		
47	EA0150EA0	FASTENER	BRAKE PIPINGS		
48	FD0145115B	HOSE,FUEL-MAIN PIPE	FUEL PIPINGS		
49	FD0145713	HOSE,FUEL	FUEL PIPINGS	Image①	
50	993590814M	HOSE	FUEL PIPINGS	Image②	
51	993590815M	HOSE	FUEL PIPINGS	Image②	
52	998780412	SCREW,TAPPING	FRONT BUMPER		
53	9CRB00530	SCREW-TAPPING	FRONT BUMPER		
54	FD0150646B	CLIP,BELTLINE MOULD	BODY MOULDINGS		
55	BM8951037	SCREW,ADJUST	HEAD LAMPS	Image①	
56	BR70510E1	FASTENER,LAMP	HEAD LAMPS	Image②	
57	FD0151025	FASTENER,LAMP	HEAD LAMPS	Image③	
58	FD0151037	SCREW,ADJUST	HEAD LAMPS	Image④	
59	FD0151047	SCREW,ADJUST	HEAD LAMPS	Image⑤	
60	FC4251036	SPRING,ADJUST	HEAD LAMPS	Image⑥	

No.	Part No.	Part Name	Category	Note	Image
61	B4815075X	SCREW,HEAD LAMP BEZE	HEAD LAMPS		
62	NA0151669	BOOTS,MOTOR-RETRACT	HEAD LAMPS		
63	NA0151SA8	WASHER	HEAD LAMPS		
64	G22551274B	LENS,LICENCE LAMP	LICENSE LAMPS		
65	B48250792	GROMMET,SCREW			
66	FB0156786A	RUBBER(C),CUSHION-BO	BONNET		
67	997350640	SCREW,TAPPING	FRONT DOOR		
68	F10068DJYC	GARNISH(L),DOOR	FRONT DOOR		
69	887161219A	GROMMET	HEATER		
70	H38466121	SPRING,CANCEL CAM	COMBI SWITCHES		
71	H380661A5	CLUMP,CORD-COMB.SWIT	COMBI SWITCHES		
72	GJ2168885B17	FASTENER	CEILING TRIMS		
73	9YA520601A	BOLT			

RX-7(FC) RESTORATION PARTS LIST

No.	Part No.	Part Name	Category	Note	Image
1	FB015681X	FASTENER, DUCT PANEL			
2	998330410	SCREW	AIR CLEANER		
3	907976612	SET BOLT	AIR CLEANER		
4	997970510	BOLT			
5	N31820341A	HOSE, VACUUM	EMISSION CONTROL		
6	N37014606	TUBE NO.1, AIR	OIL PUMP	Image①	
7	N37014607	TUBE NO.2, AIR	OIL PUMP	Image②	
8	N37014608	TUBE NO.3, AIR	OIL PUMP	Image③	
9	N37014609	TUBE NO.4, AIR	OIL PUMP	Image④	
10	N31814616A	TUBE, AIR INLET	OIL PUMP		
11	N32615202	RUBBER, MOUNT	COOLING SYSTEM		
12	999636315	ADJUST SHIM	M/T GEARS	W/O TURBO	
13	M50117651	WASHER, THRUST	M/T GEARS	W/O TURBO	
14	M50117653	WASHER, THRUST	M/T GEARS	W/O TURBO	
15	M50117654	WASHER, THRUST	M/T GEARS	W/O TURBO	
16	M50117655	WASHER, THRUST	M/T GEARS	W/O TURBO	
17	FB0126800A	LEVER(R), OPERATING	REAR BREAK		
18	FB0126810A	LEVER(L), OPERATING	REAR BREAK		
19	M0A127238A	SEAL, OIL			
20	907971512	SET BOLT	FUEL TANK		

